

CDMA Activation-Verizon

Activating your DM1000 with cellular service from Verizon is quick and easy. Follow these steps if your unit was not activated at your Verizon Wireless store, and you are activating the phone yourself.

- 1 Assemble your phone and connect it to electrical power as described in the user guide.
- 2 Contact your local Verizon Wireless agent and state that you would like activate the Waxess HomeCel DM1000C. Provide the agent with the ESN (MEID) for your unit. Once this activation process is complete and you have set up a wireless plan for your unit, proceed to the next steps.
- 3 Confirm that the **CEL** indicator displays in the base unit's LCD when the unit connects with the local Verizon Wireless network.
- 4 Press **Speaker**, so you can perform the activation with your hands free.
- 5 Press ***228**, then press **CEL**.
- 6 Follow the automated instructions from Verizon Wireless Programming. The unit's status displays in the LCD. The message "The unit has been successfully programmed" indicates your unit is ready.

Refer to the enclosed material and www.verizonwireless.com/support for more features and specific instructions from your service provider.

DM1000

Copyright © 2010 Waxess